

Vehicle Dynamic Suspension - Rear Suspension Height Sensor

Removal and Installation

Removal

NOTE: This sensor is only fitted to vehicles with Xenon headlamps and is installed on the LH side of the vehicle.

NOTE: Removal steps in this procedure may contain installation details.



1.  **WARNING:** Make sure to support the vehicle with axle stands.

Raise and support the vehicle.

2. Remove the wheel and tire.


Refer to: [Wheel and Tire](#) (204-04 Wheels and Tires, Removal and Installation).

3. Torque: 10 Nm



E 79391

- 4.



E79392

Installation

1. To install, reverse the removal procedure.
2. Using Land Rover approved diagnostic equipment, calibrate the sensor.